

- If a service reminder indicator or warning buzzer comes on 127
- If your vehicle will not start 320
- If your engine stalls while driving 323
- If your vehicle overheats 324
- If you have a flat tire 325
- If your vehicle needs to be towed 337
- Tips for driving during break-in period 277
- How to start the engine 306
- General maintenance 355
- Complete index NO TAG

Tire inflation pressure: See page 397.

U)