

SECTION 1- 1

OPERATION OF INSTRUMENTS AND CONTROLS



Overview of instruments and controls

Instrument panel overview 2


Instrument cluster overview 7

Indicator symbols on the instrument panel 8

'06 Rav4_U (L/O 0601)

Instrument panel overview


►View A



1. Side defroster outlets
2. Side vents
3. Instrument cluster
4. Center vents
5. Auxiliary box
6. Power door lock switches
7. Power window switches
8. Glove box
9. Automatic transmission selector lever
10. Rear console box
11. A/V input adapter
12. Power outlet (115 VAC)
13. Power outlet (12 VDC)
14. AUX adapter
15. Power rear view mirror control switches
16. Parking brake lever
17. Cup holders
18. Hood lock release lever
19. Window lock switch

'06 Rav4_U (L/O 0601)

►View B (with manual air conditioning system)




1. Instrument panel light control dial
2. Headlight, turn signal and front fog light switches
3. Audio remote control switches
4. Wiper and washer switches
5. Four-wheel drive lock switch (four-wheel drive models) or "AUTO LSD" switch (two-wheel drive models)
6. Audio system
7. Emergency flasher switch
8. Front passenger occupant classification indicator light
9. Air conditioning controls
10. Clock display
11. Rear window and outside rear view mirror defogger switch
12. Power outlet
13. Windshield wiper de-icer switch
14. Seat heater switch
15. Downhill assist control switch
16. Front passenger's seat belt reminder light
17. Engine immobilizer system indicator light

'06 Rav4_U (L/O 0601)

- 18. Ignition switch
- 19. Cruise control switch
- 20. Tilt and telescopic steering lock release lever

'06 Rav4_U (L/O 0601)

►View B (with automatic air conditioning system)




1. Instrument panel light control dial
2. Headlight, turn signal and front fog light switches
3. Audio remote control switches
4. Wiper and washer switches
5. Four-wheel drive lock switch (four-wheel drive models) or "AUTO LSD" switch (two-wheel drive models)
6. Audio system
7. Emergency flasher switch
8. Front passenger occupant classification indicator light
9. Air conditioning controls
10. Rear window and outside rear view mirror defogger switch
11. Clock and air conditioning display
12. Power outlet
13. Windshield wiper de-icer switch
14. Seat heater switch
15. Downhill assist control switch
16. Front passenger's seat belt reminder light
17. Engine immobilizer system indicator light

'06 Rav4_U (L/O 0601)


- 18. Ignition switch
- 19. Cruise control switch
- 20. Tilt and telescopic steering lock release lever
- 21. Power outlet main switch

►Overhead console




Without electric moon roof

- 1. Front personal lights
- 2. Auxiliary box
- 3. Electric moon roof switch



With electric moon roof

Instrument cluster overview















- 1. Tachometer
- 2. Service reminder indicators and indicator lights
- 3. Speedometer








- 4. Engine coolant temperature gauge
- 5. Fuel gauge
- 6. Odometer, two trip meters and outside temperature display




- 7. Trip meter reset knob

Indicator symbols on the instrument panel

BRAKE or 	Brake system warning light*1		Low fuel level warning light*1
	Driver's seat belt reminder light*1	ABS or 	Anti-lock brake system warning light*1
PASSENGER 	Front passenger's seat belt reminder light*1		Open door warning light*1
	Charging system warning light*1		SRS warning light*1
	Low engine oil pressure warning light*1	A/T OIL TEMP	Automatic transmission fluid temperature warning light*1
 CHECK or 	Malfunction indicator lamp*1	VSC	Vehicle stability control system/traction control system warning light*1
			Tire pressure warning light*1
		4WD	"4WD" warning light*1

'06 Rav4_U (L/O 0601)

P/S	Electric power steering system warning light* ¹
	Low windshield washer fluid level warning light* ¹
MAINT REQD	Engine oil replacement reminder light* ¹
	"AIRBAG ON" and "AIRBAG OFF" indicator lights
	Headlight low beam indicator light
	Tail light indicator light
	Headlight high beam indicator light
	Turn signal indicator lights
	Front fog light indicator light

PRND 3 2 L	Automatic transmission indicator lights (4- speed)
PRND 4 3 2 L	Automatic transmission indicator lights (5- speed)
	Four-wheel drive lock indicator light
	Slip indicator light
AUTO LSD	"AUTO LSD" indicator light
	Downhill assist control system indicator light
CRUISE	Cruise control indicator light* ²

*¹: For details, see "Service reminder indicators and warning buzzers" on page 127 in Section 1-6.

*²: If this light flashes, see "Cruise control" on page 166 in Section 1-7.

'06 Rav4_U (L/O 0601)